



MAXURETHANE®

INJECTION CLEANER

CLEANER AGENT FOR WATER-REACTIVE AND POLYURETHANE-BASED INJECTION RESINS

DESCRIPTION

MAXURETHANE® INJECTION CLEANER is a special agent for flushing and cleaning of **DRIZORO®** injection resins formulated with water-reactive polyurethane-based resins.

APPLICATION FIELDS

- General cleaning up and conditioning of tools, mixing equipment, hoses and injection pumps of polyurethane-based injection resins of **MAXURETHANE® INJECTION** range.

APPLICATION INSTRUCTIONS

All tools, mixing equipment and injection pump should be cleaned with **MAXURETHANE® INJECTION CLEANER** immediately after use or if works are interrupted for a long period, i.e. more than 20 minutes. Do not leave resins in the pump for an extended time. A standard cleaning procedure is:

- Purge the equipment of the injection resins used.
- Do an initial flush with the cleaner and discard of the liquid.
- After purging the majority of resin, use and circulate **MAXURETHANE® INJECTION CLEANER** through pump for at least 5 minutes at a high pressure and re-circulate. Use enough cleaner.
- Clean the pump and hoses thoroughly and frequently.

CONSUMPTION

Depending on use. Amount of liquid is determined by the pump size. Thus, the larger the pump, the hoses and its capacity, the more quantity is needed.

IMPORTANT INDICATIONS

- Polyurethane-based injection resins are water-reactive. Do not use water with the injection pump.
- Use only with adequate ventilation.
- Do not use with **MAXURETHANE® INJECTION LV**.
- When using, keep away from heat, flame and sources of ignition.
- Do not add solvents or any other compounds to **MAXURETHANE® INJECTION CLEANER**.
- For further information and other uses not specified in this Technical Bulletin consult our Technical Department.

PACKAGING

MAXURETHANE® INJECTION CLEANER is supplied in 5 litres or 25 litres metallic drums.

STORAGE

Twelve months in its original unopened containers in a dry and covered place, with temperatures between 5 °C and 30 °C. Store in a ventilated area, protected from humidity, direct sunlight and frost.

SAFETY AND HEALTH

MAXURETHANE® INJECTION CLEANER

is a flammable liquid so all storage, transport and handling precautions must be observed for this kind of product. Do not smoke in working areas and provide adequate ventilation. Keep away packaging from heat and ignition sources.

Skin and eye contact must be completely avoided. Do not work without the protection of rubber gloves and safety goggles. In case of eye contact, rinse immediately with

clean water but do not rub. In case of skin contact, wash with abundant water and soap. Seek medical assistance if irritation persists. If ingested, seek immediate medical assistance. Do not induce vomiting.

For further information, Safety Data Sheet of **MAXURETHANE® INJECTION CLEANER** is available by request.

Disposal of the product and its empty packaging must be made by the final user and according to official regulations.

TECHNICAL DATA

Characteristics of the product	
Appearance	Low viscosity liquid
Colour	Clear/ colourless
Density (g/cm ³)	0,95 ± 0,05
Boiling point (°C)	153
Flash point (°C)	58

GUARANTEE

The information contained in this leaflet is based on our experience and technical knowledge, obtained through laboratory testing and from bibliographic material. **DRIZORO®, S.A.** reserves the right to introduce changes without prior notice. Any use of this data beyond the purposes expressly specified in the leaflet will not be the Company's responsibility unless authorised by us. We shall not accept responsibility exceeding the value of the purchased product. The data shown on consumptions, measurement and yields are for guidance only and based on our experience. These data are subject to variation due to the specific atmospheric and jobsite conditions so reasonable variations from the data may be experienced. In order to know the real data, a test on the jobsite must be done, and it will be carried out under the client responsibility. We shall not accept responsibility exceeding the value of the purchased product. For any other doubt, consult our Technical Department. This version of bulletin replaces the previous one.



DRIZORO, S.A.

C/ Primavera 50-52 Parque Industrial Las Monjas
28850 TORREJÓN DE ARDOZ – MADRID (SPAIN)
Tel. 91 676 66 76 - 91 677 61 75 Fax. 91 675 78 13
e-mail: info@drizoro.com Web site: drizoro.com

ISO 9001
ISO 14001

BUREAU VERITAS
Certification

n° 6003176 / 6003176-MA

